




## RC200 Receiver

- 1 - Ground (Green)
  - 2 - Ground (Green)
  - 3 - Neutral
  - 4 - Hot 120VAC
  - 5 - Direction 1 ( Black )
  - 6 - Direction 2 (Red)
  - 7 - Common (White)
  - \*8 & 9 N. C. Reversing Sensor
  - 10 & 11 Remote Override Switch (SPBS)
  - 12 - Coax Antenna Connection ( not supplied )
  - 13 - Standard Antenna ( supplied with unit )
- \* NOTE: If you are not using a safety device a jumper wire must be connected to terminals 8 & 9.

Do not cut antenna wire supplied with this unit.



POWER IN 120VAC  
GROUND  
NEUTRAL  
HOT

JUMPER

Antenna

N.O. SINGLE POLE  
SINGLE THROW SWITCH  
(REF#SPBS)

